
The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.

Onan

Parts Manual

DL4B GenSet




934-0222 12-86 (SPEC A and B) Replaces 5-84 (Spec A-B) Printed in U.S.A

General Information

For parts or service, contact the dealer from whom you purchased this equipment or refer to your Nearest Authorized Onan Parts and Service Center.

. To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO. and SERIAL NO. from the Onan nameplate.



For handy reference, insert "YOUR" nameplate information in the spaces above.

Index

Actuator, Electronic Governor 11 Adapter, Oil Filter 18 Alternator 27 Alternator - Components 28	Kit, Gasket - Lower End 4 Kit, Gasket - Valve Grind 6 Kit, Repair - Fuel Transfer Pump 15
Belt, Alternator 27 Block, Cylinder 4 Box, Output 44 Breaker, Circuit - AC 44	Light, Indicator 50 Line, Fuel - Fuel Return 12 Line, Fuel - Fuel Supply 15 Line, Injection 12
Breaker, Circuit - Control Mounted 50 Breaker, Circuit - Electronic Governor 11	Manifold, Exhaust 22 Manifold, Intake 21 Meters - AC 50
Cable, Battery 29 Camshaft 4 Cap, Oil Fill - Gearcase 19 Cap Call Fill - Backer Cause 10	Monitor, Engine 46 Mount, Engine - Front 31 Mount, Vibration - Engine 40 Muffler 34
Cap, Oil Fill - Rocker Cover 19 Cap, Pressure 36 Chassis 40 Clamp, Injection Line - Early Spec A 21	Paint - Touch Up 52 Pan, Oil 16 Panel, Control - Generator Set 50
Clamp, Injection Line - Late Spec A 12 Cleaner, Air 20 Connection, Coolant Heater 23 Connector, Coolant Outlet 23	Pickup, Oil 16 Piston 4 Plug, Glow 31 Pulley, Alternator 27
Control, Electronic Governor 11 Control, Generator Set 46 Cooler, Oil 4 Cover, Rocker 19	Pulley, Coolant Pump 24 Pulley, Crankshaft 24 Pump, Coolant 24 Pump, Fuel - Electric 38
Crankshaft 4 Dampener, Vibration - Control Box 44 Drain, Oil 17	Pump, Fuel Transfer 15 Pump, Injection 12 Pump, Injection - Components 14 Pump, Oil 8
Element, Air Cleaner 20	Radiator 36
Fan, Cooling 36 Filter, Fuel 15 Filter, Oil 18 Flange, Exhaust 22 Flywheel 26	Regulator Assembly, Voltage 46 Regulator Assembly, Voltage - VRA21 Components 48 Regulator Assembly, Voltage - VRAS-2 Components 49 Relay - Day Tank 38
Gauges - DC 50 Gear, Injection Pump 8 Gearcase 8	Relay, Solenoid - Heater 40 Relay, Solenoid - Start 40 Relays - Control Mounted 46
Generator 42 Governor, Electronic 11 Grille, Radiator 36 Guard, Belt - Remote Radiator 35 Guard, Belt - Standard 36 Guard, Fan 36	Sealant, Thread 52 Sender, Oil Pressure 32 Sender, Water Temperature 24 Shroud, Fan 36 Spacer, Fan 36 Starter 29
Harness, Wiring - Engine to Control 44 Harness, Wiring - Generator to Control 44 Harness, Wiring - Generator Control Panel 50	Starter - Components 30 Strap, Ground - Control 46 Strap, Ground - Engine 40 Switch, Low Coolant Level 37 Switch, Low Engine Temperature 6
Harness, Wiring ~ Remote Control 46 Harness, Wiring ~ Voltage Regulator ~ VRA21 48 Head, Cylinder 6	Switch, Oil Pressure 32 Switch, Push 50 Switch, Rotary 50 Switch, Tap - Dual Phase Selector 44
Heater, Engine Coolant 33 Hood, Air Cleaner 20 Hose, Radiator 36 Housing, Flywnes 25	Switch, Thermostat 24 Tank, Day 38 Thermostat 24
Housing, Generator Set 41 Housing, Radiator 36	Transformer, Current 44 Tube, Oil Fill - Gearcase 19
Indicator, Oil Level 16 Indicator, Service - Air Cleaner 20 Injector, Fuel 12	

Introduction

This parts manual applies to the standard generator sets as listed below. Parts are arranged in groups of related items and each illustrated part is identified by a reference number corresponding to the same reference number in the parts list. Unless otherwise mentioned in the description, parts are interchangeable between models. All references in the parts description that pertain to specification letter differences for replacement parts are for the model listed on the identification. cation label affixed to the generator set control. Throughout this manual left (non-accessory) and right (accessory) sides are determined by facing the rear or generator end of the set.

Set Data Table

MODEL IDENTIFICATION	RATING	MODEL IDENTIFICATION	RATING
30.0 DL4B-*/#@	30,000 WATTS	33.0 DL4B-*/#@	33,000 WATTS


Electrical Data Table

*VOLTAGE CODES	VOLTS	HERTZ	WIRE	PHASE	NOTES
9XR 15R	347/600 120/208 120/240 127/220 139/240 240/416 254/440	60 60	6 12	3 3	+
515R	277/480 110/190 110/220 115/200 115/230 120/208 127/220 220/380 230/400 240/416 254/440	50	12	3	+

^{* -} Voltage codes follow model letter designations. # - Specification number: Number 1 is standard, all others indicate variations.


^{@ -} Specification letter: Letter advances (A to B, B to C, etc.) with major manufacturing changes.

^{+ -} These generators are reconnectable, refer to Operator's Manual for wiring data.




Cylinder Block

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	110-3291	1	Block Assembly, Cylinder	23	102-0975	1	Gasket, Oil Cooler Cover
			(Includes Parts Marked *)	24	102-0980	1	Cover, Oil Cooler
2	110-2978	2	*Pin, Cylinder Head Alignment	25	114-0313	4	Rod Assembly, Connecting (Includes Finished Bearing,
3	720-1801	10	*Screw, Cap - Hex Head - Special	26	114-0316	4	Bolts and Nuts) Bushing, Connecting Rod
4 5	740-1801	10	*Washer, Flat - Special				(Semi-Finished)
5	517-0141		Plug, Cup * 50.8 Stainless Steel	27	114-0315	8	Bolt, Connecting Rod
	517-0141	4 2	* 12.7 MM Steel	28 29	114-0318	8	Nut, Connecting Rod Bearing, Connecting Rod
	517-0146	1	* 31.75 MM Stainless Steel	23			(Half)
	517-0250	ī	54.37 MM Stainless Steel		114-0319	8	Standard
	01. 0200	~	(Oversize)		114-0319-01	ě	0.25 MM Undersize
6	517-0140	1	*Plug, Welch (57.15 MM) Steel		114-0319-02	8	0.50 MM Undersize
7			Pin, Alignment		114-0319-03	8	0.75 MM Undersize
	775-0074	2	* 8 MM x 20 MM	30			Piston and Pin Kit (Includes
	775-0089	2	* 10 MM × 20 MM				Retaining Rings)
	775-0078	2	* 8 MM × 40 MM		112-0201	4	Standard
8	101-0511	1	*Bearing, Camshaft - Front		112-0202	4	0.25 MM Oversize
9	101-0471	4	*Bearing, Camshaft -		112-0203	4	0.50 MM Oversize
			Intermediate and Rear		112-0204	4	0.75 MM Oversize
10	123-1613	1	*Valve Assembly, Pressure		112-0205	4	1.0 MM Oversize
			Relief (Includes Parts		112-0165	4	Pin, Piston
		_	Marked #)		518-0409	8	Ring, Retaining - Piston Pin
11	123-1515	1	#Body, Relief Valve	33			Ring Kit, Piston
12	123-1514	1	#Piston, Relief Valve		113-0233	4	Standard
13	123-1508	1	#Spring, Relief Valve		113-0234	4	0.25 MM Oversize
14	518-0410	1	#Ring, Retaining		113-0235	4	0.50 MM Oversize
15 16	505-0274	4	*Plug, Pipe - Steel (1/8")		113-0236	4	0.75 MM Oversize
17	516-2102 123-1514	1	*Pin, Regulator Valve Spring *Piston, Regulator Valve	34	113-0237 104-1508	1	1.0 MM Oversize Crankshaft and Gear
18	123-1511	1	*Spring, Regulator Valve	34	104-1506	1	(Includes Key)
19	740-1004	i	*Washer, Flat (M6)	35	168-0170	1	Kit, Gasket - Lower End
20	140 1004	•	Bearing Kit, Main (Includes		104-1138	î	Gear, Crankshaft
			Upper and Lower Bearing	37	515-0245	î	Key - Crankshaft Gear
			Half)	38	101-0584	ī	Plate, Rear Seal
			Front	39	509-0203	ī	Seal, Oil - Rear (Includes
	101-0689	1	Standad			_	Wear Sleeve)
	101-0690	1	0.25 MM Undersize	40	101-0600	1	Gasket, Rear Seal Plate
	101-0691	1	0.50 MM Undersize	41	718-1037	8	Screw, Cap - Hex Head
	101-0692	1	0.75 MM Undersize				$(M8 \times 25 MM)$
			Center	42	740-1006	8	Washer, Flat (M8)
	101-0681	1	Standard		105-0517	1	Camshaft
	101-0682	1	0.25 MM Undersize		105-0515	1	Gear, Camshaft
	101-0683	1	0.50 MM Undersize		105-0534	1	Retainer, Camshaft
	101-0684	1	0.75 MM Undersize		515-0245	1	Key - Camshaft Gear
			Intermediate (Except	47	115-0275	8	Tappet
	101 000		Center)	48	720-1054	6	Screw, Cap - Hex Head
	101-0685	2	Standard	40	705 1054	10	(M10 x 25 MM)
	101-0686	2	0.25 MM Undersize	49	725-1054	10	Screw, Socket Head
	101-0687 101-0688	2	0.50 MM Undersize	EΛ	504-0029	1	(M8 x 40 MM)
	101-0000	2	0.75 MM Undersize		504-0028	1	Valve, Coolant Drain Damper, Crankshaft Pulley
	101-0677	1	Rear	51	104-1551	1	Damper, Grankshart Pulley
	101-0677 101-0678	1 1	Standard 0.25 MM Undersize				
	101-0679	1	0.50 MM Undersize	* _	Parte Includ	ed in	110-3291 Cylinder Block
	101-0680	1	0.75 MM Undersize	-	Assembly	eu III	TTO SEST OF INICEL BLOCK
21	102-1020	1	Cooler, Oil	# -		ed in	123-1613 Pressure Relief
22	102-0973	1	Gasket, Oil Cooler	er.	Valve Assemb		110 1010 11000010 1101101
		-				. /	



Cylinder Head


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	110-3201	1	Head Assembly, Cylinder	11			Plate, Valve Spring Wear
			(Includes Guides, Seats,		110-2991	8	Spec A
			Cup Plugs, Valves, Springs,		110-2991	4	Spec B (Exhaust)
			Breather Tubes, Spacers, Water Pump Adapter,	12	110-3432	4	Spacer, Valve Spring (Intake) Spec B
			Retainers, Collets, Wear	13	110-3228	8	Seal Assembly, Valve Stem
			Plates, Sleeves and Seals)	14	110-2979	4	Sleeve, Sealing
2	110-3285	1	Head, Cylinder (Includes	15	309-0269	1	Switch, Low Engine
			Seats, Sleeves, Spacers,				Temperature (\$5) Controls
			Cup Plugs and Guides)				With 9 Indicator Lights
3			Guide, Valve (Semi-Finished)	16	720-1802	18	Screw, Cap - Hex Head
	110-3495	4	Intake (Standard)				$(M12 \times 130 MM)$
,	110-3496	4	Exhaust (Standard)	17	740-1801	14	Washer, Flat (M12)
··· 4			Seat, Valve	18	110-3012	1	Gasket, Cylinder Head
			Intake (Not Original	19			Stud, Rocker Arm
			Equipment)		115-0204	4	Short
	110-2839	4	Spec A		115-0270	4	Long
			Spec B	20	115-0313	2	Guide, Push Rod
	110-3226-01	4	Standard	21	508-0228	2	Grommet
	110-3226-02	4	.25 MM Oversize	22	115-0253	8	Pushrod
	110-3226-03	4	.50 MM Oversize	23	120-0919	1	Tube, Rocker Arm Oil
			Exhaust	24	502-0003	1	Connector, Inverted Male
	110-2781-01	4	Standard	25	115-0316	8	Arm, Rocker
	110-2781-02	4	.25 MM Oversize	26	115-0202	8	Ball, Rocker Arm
	110-2781-03	4	.50 MM Oversize	27	526-2119	8	Washer, Flat
5			Plug, Cup	28	115-0315	8	Locknut, Rocker Arm
	517-0142	7	38.1 MM	29			Adapter, Water Pump
	517-0146	4	31.75 MM		110-3045	1	Standard
	517-0162	4	19.05 MM		110-3490	1	0.5 MM Oversize
6	110-3039	4	Plug, Hot (Swirl)	30	123-1536	2	Tube, Breather
7			Valve	31	800-2085	1	Screw, Cap - Hex Head
	110-3066	4	Intake				$(M10 \times 20 MM)$
	110-2840	4	Exhaust	32	740-1008	1	Washer, Flat (M10)
8	110-3300	8	Spring, Valve	33	110-3245	8	Cap, Valve Stem (Not Used
9	110-3015	8	Retainer, Valve Spring				on Some Early Models)
10	110-2752	16	Collet, Valve Lock	34	168-0159	1	Kit, Gasket - Valve Grind




Gearcase

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	105-0513	1	Gear, Idler (Includes	19	740-1006	7	Washer, Flat (M8)
			Finished Bearing)	20	103-0746	1	Gearcase (Includes Oil Seal
2	105-0519	1	Bearing, Idler Gear				and Oil Fill Tube)
			(Semi-Finished)	21	509-0191	1	Seal, Oil (Includes Wear
3	105-0508	1	Shaft, Idler Gear				Sleeve)
4	526-2127	1	Washer, Flat (M10)	22	103-0731	1	Gasket, Gearcase
5	718-1064	1	Screw, Cap - Hex Head	23			Screw, Cap - Hex Head
			$(M10 \times 75 MM)$		718-1046	2	$M8 \times 70 MM$
6	103-0716	1	Backplate, Gearcase		718-1043	5	$M8 \times 55 MM$
7	120-0983	1	Shaft, Oil Pump Idler Gear	24			Washer, Flat
8	120-0885	1	Gear, Oil Pump Drive		740-1006	4	M8
9	718-1035	1	Screw, Cap - Hex Head		740-1010	4	M12
			$(M8 \times 16 MM)$	25	103-0735	1	Cover, Injection Pump Gear
10	526-2106	1	Washer, Flat	26	509-0263	1	Seal, O-Ring
11	120-1063	1	Gear, Oil Pump Idler	27			Screw, Cap - Hex Head
			(Includes Finished Bearing)		718-1048	1	$M8 \times 80 MM$
12	120-1041	1	Bearing, Oil Pump Idler Gear		718-1044	2	$M8 \times 60 MM$
			(Semi-Finished)		718-1036	1	$M8 \times 20 MM$
-	526-2107	1	Washer, Flat	31	718-1041	2	Screw, Cap - Hex Head
14	718-1035	1	Screw, Cap - Hex Head				$(M8 \times 45 MM)$
			$(M8 \times 16 MM)$	32	120-0979	1	Bearing, Oil Pump Drive
15	725-1802	1	Screw, Hex Socket Set				Shaft
			$(M16 \times 16 MM)$	33	120-1015	1	Pump Kit, Oil (Includes
16	103-0733	1	Gasket, Gearcase Backplate				Drive Shaft Bearing)
17			Screw, Cap - Hex Head	47		1	Plate, Timing
	718~1037	1	$M8 \times 25 MM$	48	815-0578	2	Screw, Cap - Hex Head
	718-1039	1	$M8 \times 35 MM$				$(M6 \times 12.5 MM)$
18	725-1801	2	Screw, Low Socket Head Cap (M8 × 16 MM)	49	147-0427	1	Gear, Injection Pump

Electronic Governor




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	151-0566	1	Actuator, Governor	11	151-0605	1 '	Control Covernor (A12)
2	800-0006	4	Screw, Cap - Hex Head (1/4-20 x 7/8")		813-0103	5	Control, Governor (A12) Screw, Machine - Round Head (#10-32 x 3/4")
3	850-0040	4	Washer, Lock - Spring (1/4")	13	850-0030	5	Washer, Lock - Spring (#10)
4	150-1996	1	Bracket, Mounting		338-1705	1	Harness, Wiring - Includes
5	151-0567	1	Arm, Governor (Includes		000 1100	•	Relay
			Screw and Nut)	15	307-1886	1	Relay
6	150-1923	1	Rod, Governor Control	16	320-0540	1	Breaker, Circuit - 15 Amp
7	800-2071	4	Screw, Cap - Hex Head (M8 x 90 MM)			-	(CB13) Includes Mounting
8	870-0131	2	Nut, Hex - with ET (#10-32)	17	338-1765-01	1	Cable, Magnetic Pickup (60")
9	150-0939	2	Joint, Ball	18	151-0603-02	ī	Sensor, Magnetic Speed
10	151-0437	1	Kit, Throttle Modification (Fuel Injection Pump)	10	202 0000 02	•	ochiadi, magnetit opeed



Fuel Injection


REF No.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	147-0462-08	1	Pump, Fuel Injection (See Separate Page for Components)	14	147-0617 147-0618	As Req. As Req.	
2	520-2403	3	Stud, Injection Pump (M8)	. `	147-0619	As Req.	
	526-2106	3	Washer, Flat (M8)		147-0620	As Req.	0.92 MM
4	750-1006	3	Nut, Hex (M8)		147-0621	As Req.	
5	147-0675	ī	Line, Fuel Injection (No. 1)		147-0622	As Req.	
6	147-0676	ĩ	Line, Fuel Injection (No. 2)		147-0623	As Req.	
7	147-0677	1	Line, Fuel Injection (No. 3)		147-0624	As Req.	
8	147-0678	1	Line, Fuel Injection (No. 4)		147-0625	As Req.	
9	147-0562	4	Injector, Fuel (Includes		147-0626	As Req.	
			Seal)		147-0627	As Req.	
10	147-0436	4	Seal, Injector		147-0628	As Req.	
- 11			Clamp, Fuel Line (Use began		147-0629	As Req.	
			during later portion of		147-0630	As Req.	
			Spec A)		147-0631	As Req.	
	147-0680	2	Clamps Two Lines		147-0632	As Req.	
	147-0679	1	Clamps Four Lines		147-0633	As Req.	
12	502-0733	1	Connector		147-0634	As Req.	1.48 MM
13	502-0057	1	Tee, Pipe - Special		147-0635	`As Req.	
					147-0636	As Req.	1.56 MM
		•	Control of the contro		147-0637	As Req.	1.60 MM
					147-0638	As Req.	1.64 MM
					147-0639	As Req.	1.68 MM
					147-0640	As Req.	1.72 MM
					147-0641	As Req.	1.76 MM
					147-0642	As Req.	1.80 MM
			•		147-0643	As Req.	1.84 MM
					147-0644	As Req.	1.88 MM
					147-0645	As Req.	1.92 MM
					147-0646	As Req.	
				15		4	Tip, Nozzle
				16	501-0094	1	Line, Flexible Fuel - 60" (Fuel Return)

Fuel Injection Pump Components




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	147-0462-08 147-0592	1	Pump, Fuel Injection	11	147-0583	1	Seal, Locking Plate
1		1	Strap, Terminal Grounding	12	147-0582	2	Seal, Pivot Shaft
2	147-0593	1	Solenoid and Frame Kit	13	147-0581	1	Seal, Advance Screw Hole Plug
3	147-0591	2	Washer, Terminal Insulating	14	147-0580	2	Seal, Head Locating Screws
4	147-0590	1	Gasket, Governor Cover	15	147-0579	1	Connector, Return Line
5	147-0589	1	Clip, Shaft Retaining		147-0578	+	
6	147-0588	2	Seal, Throttle Shaft	17	509-0265	1	Nut, Drive Shaft
7	147-0587	2	Washer, Throttle Shaft Seal	11	309-0263	1	Seal, Pilot Tube
ė	147-0586	1	Washer, Guide Stud				
-		1					
9	147-0585	1	Gasket, Timing Line Cover	NOT	E: For comp	onent n	arts not listed contact
10	147-0584	1	Seal, Return Line Connector			urer sh	own on nameplate.

Fuel System




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	149-2067	1	Pump Kit, Fuel Transfer	12	502-0768	2	Sleeve, Flareless Line
			(Includes Mounting Gasket)	13	502-0769	2	Nut, Flareless Line
2	149-1728	1	Gasket, Mounting	14	502-0736	1	Plug
3	718-1021	3	Screw, Cap-Hex Head (M6 x 20 MM)	15	501-0441	1	Line, Flexible Fuel - 40" (Fuel Supply)
4	740-1004	3	Washer, Flat (M6)	16	149-1772	1	Line, Fuel
5	149-1732	1	Rod, Push	17	149-1793	ĩ	Line, Fuel
6	149-1759	ī	Filter Assembly (Includes	18	149-1800	ī	Grommet, Fuel Line
			Filter, Base, Clips and Grommet)	19	503-1055	1	Line, Fuel Return (Flexible) 380 MM Long
7	149-1758	1	Filter, Fuel	20	503-1054	1	Line, Fuel Return (Flexible)
8	149-1771	2	Clip, Fuel Filter		000 2004	-	25 MM Long
9	725-1074	2	Screw, Cap - Socket Head (M10 x 20 MM)	21	503-1053	3	Line, Fuel Return (Flexible) 180 MM Long
10	740-1008	2	Washer, Flat (M10)	22	502-0738	1 .	Connector, Male - Barbed
11	502-0774	ī	Elbow, Fuel Pump Outlet		149-2069	ī	Repair Package - Fuel Pump




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	123-1439	1	Indicator, Oil Level	6	102-1272	1	Pen Odl (feel de Alex
2	120-1008	1	Pickup Kit, Oil	J	102 1212	1	Pan, Oil (Includes Adapter, Plugs and Oil Drain Gaskets)
			(Includes Gasket)	7	102-0981	1	Gasket, Oil Pan
3	120-0917	1	Gasket, Oil Pickup	8	815-0547	28	Screw, Cap - Hex Head
4			Screw, Cap - Hex Head	•	010 000	20	(Includes Washer) -
	718-1044	2	M8 × 60 MM		-		200 200 200
	718-1036	. 2	M8 x 20 MM	9	102-1147		
5	740-1006	4		. •		1	Gasket, Oil Drain Plug
Ŭ	140 1000	-	Washer, Flat (M8)	10	102-1146	1	Plug, Oil Drain


Oil Drain Hardware



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0382	1	*Clamp, Hose	8	501-0478	1	#Line, Oil Drain (20")
2	503-1069	1	*Hose, Oil Drain (14")	9	101 1237	1	#Adapter, Oil Drain
3	502-0415	1	*Adapter, Pipe to Hose	10	102-1147	1	#Gasket
4	504-0011	1	*Valve, Shutoff				· · · · ·
5	102-1235	1	#Bracket, Oil Drain				
6	502-0876	1	#Cap, Pipe	* -	Used During	α Early	Portion of Spec A
7	508-0250	1	#Grommet				Later Portion of Spec A




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF No.	PART NO.	QTY USED	PART DESCRIPTION
1	122-0613		epter, Oil Filter Includes Gasket)	5	725-1051	3	Screw, Cap - Socket Head (M8 x 25 MM)
2	122-0635	1 Gas	ket, Adapter	6	526-2108	3	Washer, Flat (M8)
4	122-0550	1 Fil	ter, Oil	8	505-0274	1	Plug, Pipe-Countersunk (1/8")




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	115-0345	1	Cover, Rocker	6	123-1518	1	Gasket, Oil Fill Cap
2	115-0254	1	Gasket, Rocker Cover	7	123-1558	ī	Tube, Oil Fill
3	115-0320	4	Capnut, Rocker Cover	8	509-0142	ī	Seal, O-Ring
4	115-0232	4	Gasket, Capnut	9	123-1647	ī	Cap, Oil Fill
5	123-1605	1	Cap, Oil Fill (Includes Gasket)	-		•	σα ρ , στι τττ

Air Cleaner



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF No.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0354	4	Clamp, Hose	9	870-2055		Alice Collection of
2	503-1222	2	Elbow, Rubber - 90°	3	010-2033	4	Nut. Self-Tocking - Hex
3	140-1801	1	Tube, Air Inlet	10	140-0078	_	Washer Head (M8)
4	140-1791	•				2	Band, Mounting
	- · · - ·	T	Indicator, Service	11	821-2076	1	Screw, Self-locking - Hex
5	140-1787	1	Hood, Air Cleaner			•	Wooher Head (M10
6	140-1869	1	Cleaner, Air (Includes	• •		_	Washer Head (M12 x 25 MM)
•	140 1003	•	Element)	12	821-2060	2	Screw, Self-locking - Hex
7	140-1204	1	Element, Air Cleaner	13	140-1772	•	Washer Head (M10 x 20 MM)
8	821-2046	4	Screw Self-locking - Hex	13	140-1112	1	Bracket, Mounting


Intake Manifold



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF No.	PART NO.	QTY USED	PART DESCRIPTION
1	154-2460	1	Manifold Kit, Intake (Includes Plug)	5	718-1022	2	*Screw, Cap - Hex Head
2	718-1801	8	Screw, Cap - Hex Head (M8 x 85 MM) Engines Without Code 31AL		740-1004 154-2261 505-0274	2	(M6 x 25 MM) *Washer, Flat (M6) Gasket, Intake Manifold
3 4	740-1006 147-0438	8 4	Washer, Flat (M8) *Clamp, Injection Lines	•	303-0214	1	Plug, Pipe-Countersunk (1/8")


^{* -} Used During Early Portion of Spec A

Exhaust Manifold




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-2388	1	Manifold, Exhaust	6	800-2085	2	Screw, Cap - Hex Head
2	154-2162	2	Gasket, Exhaust Manifold				$(M10 \times 20 MM)$
3	800-2524	8	Screw, Cap - Hex Head	7	850-2010	2	Washer, Lock (M10)
			(M8 × 90 MM)	8	155-1916	1	Flange, Exhaust
4	740-1006	8	Washer, Flat (M8)	9	155-1920	1	Gasket, Exhaust Flange
5	154-2325	1	Gasket Exhaust Manifold				-

Coolant Outlet Connector




REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	309-0473	1	Cover, Thermostat (Includes Gasket)
2	309-0424	1	Gasket
3	725-1056	4	Screw, Cap - Socket Head (M8 x 50 MM)

Coolant Heater Connection




REF	PART	QTY	PART
NO.	NO.	USED	DESCRIPTION
1	505-0017	1	Bushing
2	502-0156	1	Elbow, Street
3	502-0153	1	Plug, Brass

Coolant Pump




REF NO.	PART NÓ.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	131-0349	1	Kit, Coolant Pump (Includes	15	131-0294	2	Gasket, Pump Mounting
	-		Mounting Gaskets)	16	309-0458	1	Kit, Thermostat (192°)
2	515-0245	1	Key - Crankshaft Pulley			_	Includes Cover Gasket
3	104-1468	1	Pulley, Crankshaft	17	131-0335	1	Gasket, Backplate
4	740-1006	4	Washer, Flat (M8)		309-0462	1	Kit, Thermostat (180°)
5	718-1035	4	Screw, Cap - Hex Head			_	Includes Cover Gasket
			$(M8 \times 16 MM)$	19	502-0317	1	Plug, Pipe (3/4")
6	131-0347	1	Pulley, Coolant Pump	20	815-0612	5	Screw, Countersunk - Flat
7	509-0264	1	Seal, C-Ring			_	Head - Torque Drive (Special
8	740-1006	3	Washer, Flat (M8)	21	309-0437	1	Switch, Thermostat - High
9	718-1044	3	Screw, Cap - Hex Head (M8 x 60 MM)			_	Engine Coolant Temperature (S1) (Opens at 202° F
10	193-0318	1	Sender, Water Temperature (E2)				Closes at 222° F.)
11	502-0775	1	Plug Pipe (3/8") Controls with 2 Indicator Lights	22	309-0436	1	Switch, Thermostat - High Engine Coolant Temperature
12	526-0283	1	Washer, Flat (M8)				(S2 - Pre-Alarm) (Opens at
13	720-1123	1	Screw, Cap - Hex Head (M16 x 60 MM)				196° F Closes at 216° F.) Controls With 9 Indicator
14	131-0324	1	Spacer, Coolant Pump				Lights

Flywheel Housing




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	101-0740-02	1	Housing, Flywheel (Includes	4	160-1292	1	Indicator, Timing
			Seal and Indicator)	5	101-0592	1	Plug, Timing Window
2	718-1078	6	Screw, Cap - Hex Head	6	101-0630	1	Seal, Flywheel Housing
_			$(M12 \times 50 MM)$	7	505-2012	1	Plug, Hex
3	740-1801	6	Washer, Flat (M12)	8	740-1014	1	Washer, Flat (M16)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	104-1503	1	Flywheel Assembly (Includes Ring Gear and Alignment Pin)	4	720-1804	6	Screw, Cap - Flange Hex Head (Special)
2 3	104-1185 104-1171		Gear, Ring Pin, Alignment	5	740-1008	6	Washer, Flat (M10)

Alternator




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	511-0147-07	2	Belt	13	800-2058	4	Screw, Cap - Hex Head
2	191-1333	1	Pulley			•	(M8 × 25 MM)
3	800-2060	1	Screw, Cap - Hex Head	14	856-0010	1	Washer, Lock - EIT (3/8")
			$(M8 \times 35 MM)$	15	332-1292	1	Terminal Assembly (Includes
4	850-2008	4	Washer, Lock - Spring (M8)			-	Parts Marked *)
5	526-2106	1	Washer, Flat (M8)	16	332-1281	1	*Bracket, Terminal
6	191-1541	1	Spacer	17	809-0035	ī	*Screw, Sheet Metal - Round
7	191-1615	1	Strap, Adjusting			-	Head (#8 x 3/4")
8	800-2100	1	Screw, Cap - Hex Head	18	508-0015	1	*Washer, Fiber
			$(M10 \times 100 MM)$	19	870-0196	1	*Nut. Insulation
9	860-2009	1	Nut, Hex (M10)	20	718-1072	2	Screw, Cap - Hex Head
10	191-1321	1	Spacer			_	(M12 × 20 MM)
11	191-1525	1	Alternator (37 Amp) See	21	740-1010	2	Washer, Flat (M12)
			Separate Page for Components	22	740-1008	2	Washer, Flat (M10)
12	191-1332	1	Bracket, Mounting	* -	Parts Includ	ded in	332-1292 Terminal Assembly

Alternator Components




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	191-1525	1	Alternator (Complete) Used	4			Diode, Rectifier - Positive
			on Late Models - Has No Isolation Diodes on Back		191-1452	1	Used on Early Models with Isolation Diode Assembly
			Side of Alternator (Replaces Early Models With Isolation		191-1559	1	Used on Late Models without Isolation Diode Assembly
			Diode Assembly on Back Side	5			Brush Assembly
	•		of Alternator)		191-0659	1	Used on Early Models with
1	191-0943	1	Fan, Alternator				Isolation Diode Assembly
2	191-1454	1	Diode Assembly, Isolation - Used on Early Models		191-1558	1	Used on Late Models without Isolation Diode Assembly
3			Diode, Rectifier - Negative	6			Regulator, Voltage
	191-1453	1	Used on Early Models with Isolation Diode Assembly		191-1457	1	Used on Early Models with Isolation Diode Assembly
	191-1560	1	Used on Late Models without Isolation Diode Assembly		191-1557	1	Used on Late Models without Isolation Diode Assembly
			,	7	191-1556	1	Diode, Trio - Used on Late Models without Isolator Diode Assembly

Starter




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	191-1394	1	Starter (Includes Switch Terminal Hardware) (See	7	850-2005	1 .	Washer, Lock - Spring (M5) Solenoid Terminal
			Separate Page for Components)	8	416-0618	1	Cable, Battery - 42" (Positive)
2	720-1806	2	Screw, Cap - Flanged Hex Head (M12 x 30 MM)	9	800-2110	1	Screw, Cap - Hex Head (M12 x 20 MM)
3	740-1010	2	Washer, Flat (M12)	10	856-0013	1	Washer, Lock - EIT (1/2")
4	860-2008	1	Nut, Hex (M8) B+ Terminal	11	416-0530	1	
5	850-2008	ī	Washer, Lock - Spring (M8) B+ Terminal	11	410-0330	1	Cable, Battery - 16" (Negative)
6	718-1002	1	Screw, Cap - Hex Head (MS x 8 MM) Solenoid Terminal				

Starter Components




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	191-1394	1	Stanter (Complete)	12	191-1439	1	Bracket Assembly, Center
1	191-1450	1	Screw Set	13	191-1438	- - -	Armature Assembly (Includes
2	191-1449	1	Bracket Assembly, Front	10	101 1400	•	Bearings)
			(Includes Bearing)	14	191-1437	1	Bearing, Center
5	191-1446	1	Gear	15	191-1436	1	Bearing, Rear
6	191-1445	1	Clutch		191-1435	1	
7	191-1444	ī	Cover Set (Includes Cover, Plate, Washers, Snap Ring,	10	191 1435	1	Yoke Assembly (Includes Pole Shoes, Field Coil and Positive Brushes)
			and Screws)	17	191-1434	1	Holder, Brush (Includes
8	191-1443	1	Pinion Set (Includes Pinion,				Negative Brushes)
_		_	Spring, and Stopper Set)	18	191-1433	4	Spring, Brush
9	191-1442	1	Stopper Set (Includes	19	191-1432	1	Bracket, Rear
			Stopper and Ring)	20	191-1431	1	Bolt Set
10	191-1441	1	Lever Assembly	21	191-1430	1	
11	191-1440	ĩ	Spring Set	21	131 1430	1	Switch Assembly

Glow Plug




REF	PART	QTY	PART	REF	PART	QTY	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
	333-0220	4	Plug, Glow	3	750-1002	4	Nut, Hex (M5)
	336-4131	3	Lead, Glow Plug	4	850-2005	4	Washer, Lock - Spring (M5)

Front Engine Mount



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	403-1925	1	Bracket, Mount	3	740-1010	4	Washer, Flat (M12)
2			Screw, Cap - Hex Head	4	403-1932	2	Spacer, Bracket Mounting
	718-1086	2	M12 x 90 MM (Top)				.,
	718-1802	2	M12 x 95 MM (Bottom)				


Oil Pressure Switch



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION	
1 2	193-0244 309-0169	1 Swit	der, Oil Pressure (E1) tch, Oil Pressure (S3)	4	505-0059	1	Tee, Pipe (1/8") (Controls with 9 Indicator Lights)	
3	309-0272	1 Swit Pre Des	oses at 14 lbs. Descending tch, Oil Pressure (S4 - Alarm) Closes at 20 lbs. scending (Controls with Indicator Lights)	. 5	505-0098	1	Nipple, Pipe (1/8" × 3/4") (Controls with 9 Indicator Lights)	


· . .

Engine Coolant Heater




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	333-0255-01	1	Heater, Engine Coolant 750 Watt, 120 Volt AC,	10	821-2061	2	Screw, Self-locking - Flange (M10 x 25 MM)
	333-0255-04	1	Single Phase 750 Watt, 240 Volt AC,	11	821-2033	2	Screw, Self-locking - Flange (M6 x 16 MM)
2	130-2246	1	Single Phase Plate, Mounting	12	870-2054	2	Nut, Self-locking - Flange (M6)
3	502-0156	1	Elbow, Street - 45° (1/4")	13	505-0120	1	Elbow, Pipe - 90° (3/8")
4	502-0613	1	Connector, Hose (1/4" Pipe to 5/8" Hose)			-	Used on some early Spec A models
5	502-0816	1	Connector, Hose (3/8" Pipe to 5/8" Hose)	14	502-0817	1	Elbow, Pipe to Hose - 90°
6	503-0833	1	Hose, Rubber (5/8" ID x 16")				(3/8" Pipe to 5/8" Hose)
7	503-1168	1	Hose, Rubber (5/8" ID x 35")		•		Used on some early Spec A models
8	503-0183	4	Clamp, Hose				mode (S
9	870-2056	2	Nut, Self-locking - Flange (M10)				

Muffler (Housed Set)




REF NO.	PART NO.	QTY U S ED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	505-0454		Union, Pipe (2")	7	800-2069	4	Screw, Cap - Hex Head
2	155-2007	1	Tube, Exhaust - Flexible		*		$(M8 \times 80 MM)$
3	140-0752	2	Band, Mounting	8	870-2055	4 .	Nut, Self-locking - Hex
4	155-1931	1	Shield, Heat				Washer Head (M8)
5	155-1430	4 😘 🤃	Spacer	. 9	526-2100	- я	Washer, Flat (M8)
6	155-1614	1 1	Muffler Exhaust	•		· ·	74311C1 , 1 12((110)

Belt Guard (With Remote Radiator)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF No.	PART NO.	QTY USED	PART DESCRIPTION
1	130-2792	1	Panel, Front	7	800-2056	2	Screw, Cap - Hex Head
2	800-2029	8	Screw, Cap - Hex Head	_		-	(M8 × 16 MM)
			$(M6 \times 12 MM)$	8	850-2008	2	Washer, Lock - Spring (M8)
3	850-2006	9	Washer, Lock - Spring (M6)	9	191-1678	1	Guard, Alternator
4	130-2788	1	Panel, Side	10	718-1021	1	Screw, Cap - Hex Head
5	130-2785	1	Bracket, Belt Guard (Left Hand)			-	(M6 × 20 MM)
6	130-2786	1	Bracket, Belt Guard (Right Hand)				




Cooling System

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.		QTY USED	PART DESCRIPTION
1	821-2033	21	Screw, Self-locking - Hex Washer Head (M6 x 16 MM)	17	821-2032	16	Screw, Self-locking - Hex Washer Head (M6 x 12 MM)
2	130-2298	2	Guard, Fan	18	130-2276	1	Shroud, Fan
. 3	191-1577	1	Guard, Belt	19	130-1817	1	Radiator
4	800-2071	4	Screw, Cap - Hex Head	20	130-2003	1	Cap, Pressure
			(M8 × 90 MM)	21	191-1539	1	Guard, Belt
5	740-1006	4	Washer, Flat (M8)	22	405-3182	1	Grille
6	130-2324	1	Fan (20-9/32")	23	821-2061	5	Screw, Self-locking - Hex
7	130-1876	1	Spacer, Fan (65 MM)				Washer Head (M10 x 25 MM)
8	503-0365	4	Clamp, Hose	24	870-2056	5	Nut, Self-locking - Hex
9	503-1255	1	Hose, Radiator - Upper				Washer Head (M10)
10	503-1256	1	Hose, Radiator - Lower	25	191-1579	1	Guard, Belt
11	821-0010	2	Screw, Self-locking - Hex	26	504-0003	1	Cock, Drain (1/4")
			Washer Head $(1/4-20 \times 1/2")$	27	405-3201	1	Housing - Front
12	870-2054	4	Nut, Self-locking - Hex	28	130-2270	2	Insert, Shroud
			Washer Head (M6)	29	402-0546	3	Insert, Isolator
13	130-2293	1	Support, Fan Shroud -	30	508-0248	3	Grommet, Rubber
			Right Hand	31	191-1580	1	Bracket, Support -
14	130-2294	1	Support, Fan Shroud -				Belt Guard
			Left Hand	32	191-1593	1	Bracket, Support -
15	718-1032	16	Screw, Cap - Hex Head				Belt Guard
			$(M8 \times 10 MM)$	33	191-1590	1	Bracket, Support -
16	850-2008	16	Washer, Lock - Spring (M8)				Belt Guard

Low Coolant Level Switch



REF NO.	PART NO.	QTY USED	PART DESCRIPTION					
1	193-0322	1	Switch - Coolant Level (S7)					
2	338-1691	1	Harness, Wiring (Includes Housing)					
3	323-1236	1	Housing, Connector					




XFS 1585

Day Tank


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1,	501-0528	1	Line, Fuel - Flexible (45")	15	415-0326	1	Cover, Access - Relay
2	501-0491	1	Line, Fuel - Flexible (32")	16	812-0061	2	Screw, Machine - Round Head
3	502-0916	3	Elbow, Inverted Male - 90°				(#6-32 × 3/8")
4	502-0054	1	Elbow, Street - 90°	17	870-1183	2	Nut, Self-locking - Hex
5	149-1828	1	Pump, Fuel (12 Volt DC)				Washer Head With ET (#6-32)
6	415-0321	1	Switch, Float - Liquid Level	18	307-1157	1	Spring, Holddown - Relay
			(Includes Mounting Plug)	19	307-1058	ī	Relay (12 Volt DC)
7	159-0007	1	Cap, Fuel Tank	20	323-0765	1	Socket, Relay
8	505-0054	1	Plug, Pipe - Square Head (1/4")	21	821-0014	12	Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")
9	505-0110	1	Plug, Pipe - Square	22	402-0078	4	Mount, Vibration
			Head (3/8")	23		1	Bracket, Mounting
10	821-0013	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 1")	24	870-0257	4	Nut, Self-locking - Hex
11	415-0451	1	Strap, Retaining - Tank	25	501-0492	1	Washer Head (5/16-18)
12	415-0445	1	Tank, Fuel - Day (Includes	26		1	Line, Fuel - Flexible (20")
*~	410 0440	*	Cap) (3-1/2 Gallons)	27		2	Bracket, Support - Fuel Tank
13	813-0098	1	Screw, Machine - Round Head	21	821-0018	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 5/8")
			(#10-32 × 3/8")	28	870-0212	2	Nut, Self-locking - Hex
14	850-0030	1	Washer, Lock - Spring (#10)				Washer Head $(1/4-20)$

Chassis




REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	800-2126	1	Screw, Cap - Hex Head (M12 x 110 MM)	16	870-2054	7	Nut, Self-locking - Hex Washer Head (M6)
2	402-0542	1	Insert, Isolator	17	307-1031	1′	Relay, Solenoid - Heater
3	526-0172	1	Washer, Flat (1/2" ID x			•	(Upper) (K2)
	050 0010		2-1/4" OD × $1/4$ " Thk)	18	307-1166	1	Relay, Solenoid - Start
4	850-2012	1	Washer, Lock - Spring (M12)				(Lower) (K1)
5	860-2010	1	Nut, Hex (M12)	19	337-0090	1	Strap, Ground - Engine
6	800-2186	2	Screw, Cap - Hex Head	20	853~2006	1	Washer, Lock - EIT (M6)
			$(M16 \times 120 MM)$	21	800-2110	1	Screw, Cap - Hex Head
7	526-0242	2	Washer, Flat (11/16" ID x			•	$(M12 \times 20 MM)$
_	050 0000	_	2-7/8" OD x $1/4$ " Thk)	22	332-1473	. 1	Lug, Solderless
	850-2066	2	Washer, Lock - Spring (M16)	23	856-0013	1	Washer, Lock - EIT (1/2")
9	800-2111	6	Screw, Cap - Hex Head	24	416-0828	2	Rod, J Hook (M6)
			(M12 × 25 MM)	25	416-0830	1	Bracket, Holddown - Battery
10	850-2012	6	Washer, Lock - Spring (M12)		821-2047	9	Screw, Self-locking - Hex
11	860-2010	6	Nut, Hex (M12)			•	Washer Head (M8 x 25 MM)
12	402-0540	3	Mount, Vibration	27	870-2055	9	
	403-2172	1	Skid	21	670~2055	9	Nut, Self-locking - Hex Washer Head (M8)
14	332-0602	1	Jumper, Solenoid	28	416-0847	1	Tray, Battery
15	821-2036	5	Screw, Self-locking - Hex Washer Head (M6 x 30 MM)			-	,,

Housing




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.		QTY USED	PART DESCRIPTION
1	406-0561	4	Latch, Door	11	818-0150	8	Rivet
2	405-3229	2	Door, Engine	12	405-3082	1	Grille
3	821-2033	4	Screw, Self-locking - Hex Washer Head (M6 x 16 MM)	13	821-2020	2	Screw, Self-locking - Hex Washer Head (M5 x 12 MM)
4	406-0552	2	Latch, Door	14	406-0555	1	Latch, Cover
5	895-0195	_	Stripping, Weather - Bulk	15	526-0003	8	Washer, Flat (#8)
			(Order by the foot - 7 foot	16	406-0553	4	Catch, Door
			required)	17	405-1872	4	Clip, Door
6	870-2054	18	Nut, Self-locking - Hex	18	870-2026	6	Nut, Weld (M6)
			Washer Head (M6)	19	821-2061	11	Screw, Self-locking - Hex
7	405-3240	8	Support, Corner				Washer Head (M10 x 25 MM)
8	405-3237	1	Panel, Top	20	870-2056	11	Nut, Self-locking - Hex
9	822-3073	3	Screw, Machine - Pan Head				Washer Head (M10)
			$(M4 \times 10 MM)$	21	405-3242	1	Panel, Rear
10	405-2677	1	Cover, Control	22	403-2168	1	Skid, Rear




Generator

REF	PART	QTY	PART	REF		TY	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO. U	SED	DESCRIPTION
1	800-2029	6	Screw, Cap ~ Hex Head	28	232-2959	1	Cover, Bearing
			$(M6 \times 12 MM)$	29	800-2004	2	Screw, Cap - Hex Head
2	850-2006	10	Washer, Lock - Spring (M6)				$(M5 \times 12 MM)$
3	860-2006	2	Nut, Hex (M5)		850~2005	2	Washer, Lock - Spring (M5)
4	526-2060	. 2	Washer, Flat (M5)			1	Board, Terminal
5	150-1962	1	Point, Contact		870-0212	2	Nut, Hex (1/4-20)
6	150-1964	1	Spring	33	800-2100	4	Screw, Cap - Hex Head
7	870-0171	1	Nut, Insulating				$(M10 \times 100 MM)$
8	150-1963	1	Bracket, Mounting			6	Washer, Lock - Spring (M10)
9	720-1057	1	Screw, Cap - Hex Head			1	Bell, End
			$(M10 \times 40 MM)$			1	Screen, Fan
	853-2010	1	Washer, Lock - ET (M10)	40	800-2088 1	2	Screw, Cap - Hex Head
11		3	Washer, Flat (M10)				$(M10 \times 35 MM)$
	150-2038	1	Switch, Overspeed		515-0158	1	Key - Exciter Rotor
13	526-2129	1	Washer, Flat (11 MM ID \times	42			Stator, Generator
			45 MM OD \times 5 MM Thk)			1	Code 9XR
14	232-2929	1	Spacer, Exciter			1	Code 15R
15	201-2299	1	Rotor Assembly, Exciter			1	Code 515R
			(Includes Parts Marked *)	43	201-3099	1	Rotor Assembly, Generator
16	870-0131	6	*Nut, Self-locking - Hex With				(Includes Parts Marked #)
			ET Lockwasher (#10-32)			1	#Bearing, Ball
17	526-0008	6	*Washer, Flat (#10)	45	800-2112	8	#Screw, Cap - Hex Head
18	813-0100	4	*Screw, Machine - Round Head				$(M12 \times 30 MM)$
			(#10-32 × 1/2")			8	#Washer, Flat (M12)
19	853-0008	4	*Washer, Lock - ET (#10)			8	#Nut, Hex (M10)
20		4	*Washer, Flat (#10)			8	#Washer, Lock - Spring (M10)
21	358-0069	1	*Rectifier Assembly -			8	#Washer, Flat (M10)
			Positive	50	800-2533	8	#Screw, Cap - Hex Head
22	358-0070	1	*Rectifier Assembly -				$(M10 \times 55 MM)$
			Negat ive				#Disk, Drive
23	802-2073	4	Screw, Cap - Socket Head			1	#Spacer
			$(M6 \times 45 MM)$	53	205~0161	1	#Fan
24	508-0239	-	Edging - Bulk (Order by the				
			foot - 1 foot required)				
25	220-3968	1	Stator, Exciter	* _		in	201-2299 Exciter Rotor
26		4	Washer, Flat (#10)		Assembly		
27	800-0012	2	Screw, Cap - Hex Head	# -		in	201-3099 Generator Rotor
			$(1/4-20 \times 1-3/4")$		Assembly		



Output Box


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	301-9037	2	Bracket, Support - Output	23			Plug, Plastic - 3/8" Hole
			Box - Used on some early		517-0169	4	Spec A
			models		517-0169	12	Spec B
2			Box, Output	2.4			
۷	301-8113	1			332-0941	3	Tie, Cable
		1	Spec A	25	800-2035	1	Screw, Cap - Hex Head
_	301-8978	1	Spec B			_	(M6 x 25 MM) Grounding Stud
3	821-2045	4	Screw, Self-locking - Hex	26		1	Washer, Lock - EIT (1/4")
		_	Washer Head (M8 \times 16 MM)	27		2	Washer, Flat (M6)
4	301-8112	1	Grille		860-2007	2	Nut, Hex (M6)
5	301-9038	1	Bracket, Output Box	29	821-0014	8	Screw, Self-locking - Hex
6			Cover				Washer Head (5/16-18 x
	301-8114	1	Without Circuit Breaker				1/2") Spec A
			Opening	30	308-0770	1	Switch, Tap - Dual Phase
			With Circuit Breaker				Selector (Includes Knob and
			Opening				Mounting Hardware)
	301-8896	1	Use With Westinghouse	31	303-0218	1	Knob
			and General Electric	32	812-0153	4	Screw, Machine - Round Head
			Circuit Breakers			•	(1/4-20 × 1")
	301-8898	1	Use With Heineman	33	850-0040	4	Washer, Lock - Spring (1/4")
	001 0000	-	Circuit Breakers	34	508-0055	1	Grommet, Rubber -
7	301-7572	1	Bracket, Mounting - Circuit	54	300 0033	1	
,	301 1312	1	Breaker	25	E26-00E2	4	1-3/4" Hole
	508-0257	1	Grommet, Plastic -	35	526-0052	4	Washer, Flat (1/4")
8	308-0237	1		36			Transformer, Current
_	222 1645		3-1/2" Hole		200 2000	_	(CT21, 22, 23)
9	338-1647	1	Harness, Wiring - Generator		302-0076	3	All Except Voltage Code
			to Control (Includes Plug			_	9XR (Ratio 75/5, 1VA)
10	222 1250	2	and Pins)		302-0117	3	Voltage Code 9XR
10	332-1356	3	Clamp, Insulated - DC Wiring	27	870 0057	0	(Ratio 50/5, 1VA)
1.1			Harness	31	870-0257	8	Nut, Self-locking - Hex
11			Breaker, Circuit (CB4 or				Washer Head (5/16-18)
			CB5)	20	201 0055	•	Spec B
	200 0645	4	Voltage Code 15R	38	301-8955	8	Bracket - Spec B
	320-0645	1	50 Amp, 480 Volt	39	821-0014	8	Screw, Self-locking - Hex
	320-0701	1	100 Amp, 240 Volt				Washer Head (5/16-18 x
	320-1049	1 .	125 Amp, 240 Volt				1/2") Spec B
	320-0344	1	175 Amp, 240 Volt	40	402-0527	4	Isolator, Vibration - Spec B
	320-0384	1	Voltage Code 515R -	41			Lead, Generator Output
		,	60 Amp, 480 Volt			_	Extension
12	402-0070	4	Dampener, Vibration - Spec A		226-3423	2	Two Pole Breakers
13	517-0190	1	Plug, Plastic - 3-1/2" Hole		226-3423	3	Three Pole Breakers
14			Bracket - Upper	42	800-0003	2	Screw, Cap - Hex Head
	301-8110	1	Spec A				$(1/4-20 \times 1/2")$
	301-8951	1	Spec B	43		2	Washer, Lock - Spring (1/4")
15		_	Bracket - Lower	44	812-0094	4	Screw, Machine - Round Head
	301-8109	1	Spec A				(#8-32 × 3-5/8")
	301-8952	1	Spec B	45		4	Washer, Lock - Spring (#8)
16	508-1010	1	Channel, Rubber - Used on	46	860-0008	4	Nut, Hex (#8-32)
			some early models	47	812-0063	6	Screw, Machine - Round Head
17	821-2032	14	Screw, Self-locking - Hex				(#6 ~32 × 1/2")
			Washer Head (M6 \times 12 MM)	48	821-2045	3 -	Screw, Self-locking - Hex
18	508-0051	1	Grommet, Rubber - 2" Hole				Washer Head (M8 \times 16 MM)
			(Spec B)	49	800-2054	2	Screw, Cap - Hex Head
19	338-1711	1	Harness, Wiring - Engine to				$(M8 \times 14 MM)$
			Control (Includes Grommet,	50	850~2008	2	Washer, Lock - Spring (M8)
			Plug and Sockets)	51	526-2101	2	Washer, Flat (M8)
20	508-0258	1	Grommet, Rubber -	52	323-1136	1	Plug, Circular (14 Pin) (P2)
			1-1/2" Hole	53	323~1228	11	Pin, Male
21	323-1134	1	Plug, Circular (16 Pin) (Pl)				
22			Socket, Female		•		
	323-1192	4	14-12 Gauge Wire				
	323-1195	10	18-14 Gauge Wire				



Control


REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Regulator Assembly, Voltage (See Separate Page for	18	338-1427	1	Harness, Wiring - Remote Control (30')
	305-0693-01	1	Components) Standard (VRA21)	19	815-0105	1	Screw, Machine - Round Head (Brass) (#10-32 x 1")
		4 T	Fixed Resistor	00	500 0000	_	Grounding Stud
	305-0693-02	1	External Adjust		526-0063	2	Washer, Flat - Brass (#10)
	205 0205 01		Switching Regulator (VRA21)		856-0003	2	Washer, Lock - EIT (#10)
	305-0695-01	1	Fixed Resistor	22	851-0001	1	Washer, Lock - Spring
	305-0695-02	1	External Adjust				(Brass) (#10)
_	305-0737	1	Standard (VRAS-2)		871-0010	2	Nut, Hex - Brass (#10-32)
2			Bracket, Mounting - Relay	24	821-0005	5	Screw, Self-Locking - Hex
	301-3244	1	One Socket Hole				Washer Head (#10-32 \times 1/2")
	301-7334	1	Two Socket Holes		301-5150	1	Cover, Control
3	307-1061	1	Relay - Start (K11)	26	301-6230	1	Box, Control
. 5	307-1157	3	Spring, Holddown - Relay Monitor Assembly, Engine	27	-	1	Panel, Control (See Separate Page for Components)
			(Includes Replaceable Relay	28			Receptable - Square Flange
			and Spring) (All)		323-1137	1	14 Pin (J2)
	300-2510	1	Two Light Monitoring		323-1135	1	16 Pin (J1)
			System (Standard)	29	323-1229	11	Socket, Female - Used With
	300-2453-04	1	Nine Light Monitoring				14 Pin Receptable
			System	30			Pin, Male - Used With 16 Pin
6	307-1157	1	Spring, Holddown - Relay				Receptacle
7	307-1687	1	Relay (A11K1)		323-1193	4	16-12 Gauge Wire
8	812-0061	2	Screw, Machine - Round Head		323-1194	12	18-14 Gauge Wire
			(#6~32 × 3/8")	31			Plug - Circular
9	854-0006	2	Washer, Lock - IT (#6)		323-1136	1	14 Pin (P2)
10	860-0006	2	Nut, Hex (#6-32)		323-1134	1	16 Pin (P1)
11	307-1061	1	Relay - Voltage Selector	32		-	Socket, Female - Used With
		-	(K21)				16 Pin Plug
12	307-1058	1	Relay - Run (K12)		323-1192	4	14-12 Gauge Wire
13	323-0804	1	Socket, Relay (K12)		323-1195	12	18-14 Gauge Wire
14	337-0049	1	Strap, Ground	33	323-1194	11	Pin, Male - Used With
15	856-0008	2	Washer, Lock - EIT (5/16")				14 Pin Plug
16	508-0144	1	Grommet, Rubber (1" Hole)				- · · · · · - - 3

Voltage Regulator Assembly (VRA21)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Regulator Assembly, Voltage - Complete Standard	7	315-0343	1	Reactor - Used on Switching Voltage Regulator Assemblies (VRA21L22)
	305-0693-01	1	Fixed Resistor	8	315-0343	1	Reactor (VRA21L21)
	305-0693~02	1	External Adjust	9	332-0607	1	Block, Terminal (VRA21TB2)
			Switching Regulator	10	332-2373	1	Strip, Marker
	305-0695-01	1	Fixed Resistor	11	332-2387	4	Terminal, Tab - Used on
1	305-0695-02	1	External Adjust Hanness, Wiring				Standard Voltage Regulator Assemblies
	338-1443	1	Standard Regulator	12	301-5736	1	Panel, Mounting
	338-1670	1	Switching Regulator	13			Screw, Machine - Round Head
2			Board, Voltage Regulator				(#6-32 x 3/8")
	332-2045	1	(VR21) Standard Regulator		812-0061	4	Standard Voltage Regulator Assemblies
		_	(Includes Fuses)		812-0061	6	Switching Voltage Regulator
	300-2409	1	Świtching Regulator				Assemblies
3	321-0204	2	Fuse (1/4 Amp) Used With Standard Voltage Regulator	14	870-0183	8	Nut, Self-Locking - Hex Head With ET Lockwasher (#6-32)
			Board (VR21F2,F3)	15	812-0070	2	Screw, Machine - Round Head
4	350-1190	1	Resistor - Fixed (1740 Ohms, 1/2 Watt) Used on Voltage				(#6-32 x 1-1/4") Used on Standard Voltage Regulator
			Regulator Assemblies Without				Assemblies
			External Adjust (VRA21R21)	16	812-0059	4	Screw, Machine - Round Head
5	315-0431	1	Transformer (VRA21T21)				(#6-32 × 1/4")
6	305-0524	1	Bridge, Rectifier - Used on	17	853-0003	4	Washer, Lock - ET (#6)
			Standard Voltage Regulator Assemblies (VRA21CR21)	18	812-0065	2	Screw, Machine - Round Head (#6-32 x 5/8")

Voltage Regulator Assembly (VRAS-2)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	305-0737	1	Regulator Assembly, Voltage - Complete	6	332-0607 812-0065	1	Block, Terminal (VRAS-2TB2)
1	301-9334	1	Panel, Mounting	,	012-0005	2	Screw, Machine - Round Head
2	812-0059	. 5	Screw, Machine - Round Head (#6-32 x 1/4")	8	870-0183	2	(#6-32 x 5/8") Nut, Self-Locking - Hex Head
3	853-0003	5	Washer, Lock - ET (#6)	9	350-0394	1	With ET Lockwasher (#6-32)
4	300-2880	1	Board, Voltage Regulator (VR21)	v		1	Resistor - Fixed (2000 Ohms, 1/2 Watt) Used on Voltage
5	332-2373	1	Strip, Marker				Regulator Assemblies Without External Adjust (VRAS-2R21)



Control Panel

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.		QTY USED	PART DESCRIPTION
1			Panel, Control	19			Breaker, Circuit - Field
	301-7348-01	1	Panels Without AC Meters Panels With Three Round				Used With VRA21 Voltage Regulator Assembly
	301-7348-02	1	Gauge Holes Panels With Four Round		320-1138	1	3 Amp (Dual - CB3,CB4)
	301 7348 02	1	Gauge Holes		320-0530 320-1121	1 1	5 Amp (CB3) Used With VRAS-2 Voltage
			Panels With AC Meters Panels With Three Round		200 2101	. •	Regulator Assembly - 3 Amp (CB3)
			Gauge Holes	20	302-0885	1	Meter, Time Totalizing (M4)
	301-7349-01	1	Without Emergency Stop Switch	21	302-1715	1	Tachometer (Includes Socket and Lamp (M5)
	301-9498	1	With Emergency Stop Switch		193-0330 302-1402	1 1	Gauge, Oil Temperature (M5) Ammeter - DC (M1)
	301-7349-02	1	Panels With Four Round	24	193-0352	1	Gauge, Oil Pressure (M2)
2			Gauge Holes Light, Indicator (14VDC)	25 26	193-0351	1	Gauge, Water Temperature (M3)
-			Controls With Two Light	20			Harness, Wiring - AC (Includes Socket for K11
			Monitoring System				Start Relay, Receptable and
	322-0238	1	RUN - Green (DS1)			_	Sockets)
	322-0128	1	FAULT - Red (DS2) Controls With Nine Light		338-1642-03	1	Controls Without AC Meters
			Monitoring System		338-1642-01	1	Controls With AC Meters All Except Voltage Code
	322-0238	1	RUN - Green (DS1)		***************************************	-	9XR (Also Includes
	322-0110	1	LO ENG TEMP - Red (DS2)				Resistor and Socket
	322-0109 322-0108	1 1	HI ENG TEMP - Red (DS3)				for K21 Voltage
	322-0111	1	LO OIL PRES - Red (DS4) OVERSPEED - Red (DS5)		338-1642-04	1	Selector Relay) Voltage Code 9XR
	322-0107	ī	OVER CRANK - Red (DS6)	27		2	Socket, Relay (For K11,K21
	322-0240	1	PRE HI ENG TEMP - Amber				Relays)
	322-0241	1	(DS7) PRE LO OIL PRESS - Amber	28	350-0556	1	Resistor, Fixed - 47K Ohm, 1/2 Watt (K21R22)
	322-0283	1	(DS8) SWITCH OFF - Red (DS9)	29			Harness, Wiring - DC
3	322-0263	7	Lens, Indicator Light (No				(Includes Receptacle, Pins, Plug and Sockets, where
•	022 0141	•	Legend or Lamp) Controls With				required.)
			Two Light Monitoring System		338-1643-01	1	Meters
4	202-1272	4	Meter, Frequency - AC (M21)		338-1644	1	Switches
	302-1273 302-1153	1 1	50 Hertz 60 Hertz		338-1646	1	Indicator Lights Controls With Two Light
5		-	Ammeter - AC (M23)		000 1040	+	Monitoring System
	302-1147	1	All Except Voltage		338-1645	1	Controls With Nine Light
	302-1298	1	Code 9XR Voltage Code 9XR	30	322-0308	3	Monitoring System Lamp, Pilot (DS10,DS11,DS12)
6	772 1277	-	Voltmeter - AC (M22)		322-0210	4	Socket, Lamp
	302-1148	1	All Except Voltage		322-0004	1	Lamp, Pilot (DS13)
	202-1200	1	Code 9XR	33	323-1137	1	Receptable - Square Flange
7	302-1300	1	Voltage Code 9XR Switch, Push (Remote, Stop,	34			(14 Pin) (P2) Socket, Female
-			Start) (S10)	•	323-1229	11	Used With 338-1642-01
	308-0531	1	Controls With Two Light				Wiring Harness
			Monitoring System		323-1229	5	Used With 338-1642-03
			Controls With Nine Light Monitoring System		323-1229	10	Wiring Harness Used With 338-1642-04
	308-0620	1	Standard		220 3220	10	Wiring Harness
	308-0624	1	Pennsylvania State	35	323-1135	1	Receptacle - Square Flange
۵	208-0522	1	Approved				(16 Pin) (P1) Used With
	308-0533 308-0532	1 1	Switch, Push - Pre Heat (S11) Switch, Push - Lamp Test (S12)	36			338-1643-01 Wiring Harness Pin, Male - Used With
10	303-0032	2	Knob	•••			323-1137 Receptable
11			Potentiometer - 25 Watt (R23)		323-1193	3	16-12 Gauge Wire
	303-0170	1	Used With VRA21 Voltage	27	323-1194	10	18-14 Gauge Wire
			Regulator Assembly With External Adjust	31	323-0984	3	Plug, Connector (12 Pin) (J1, J2, J3) Used With
	303-0261	1	Used With VRAS-2 Voltage				338-1643-01, 338-1644 and
			Regulator Assembly With				338-1645 Wiring Harnesses
3.0	200 0004		External Adjust	38	202 2422	•	Socket, Male (Side Feed)
12	308-0284	1 .	Switch, Rotary - Voltmeter/Ammeter (S21)		323-0488	8	Used With 338-1643-01
13	322-0211	2	Light, Pilot (DS21,DS22)		323-0488	12	Wiring Harness Used With 338-1644
14	517-0132	1	Plug, Hole				Wiring Harness
	322-0203	2	Lamp (DS14,DS15)		323-0488	10	Used with 338-1645
	322-0213	2	Lampholder		200 0010 01		Wiring Harness
17	320-1110	1	Breaker, Circuit - Remote - 7 Amp (CB1)	39	308-0813-01	1	Switch, Push - Emergency Stop (S13) Includes Knob
18	320-1110	1	Breaker, Circuit - Control - 7 Amp (CB2)				and Mounting Hardware

Paint and Thread Sealant

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
525-0305		_	Paint, Green - Enamel (13 oz. Pressurized Spray Can)
	518-0452	_	Sealant. Thread (50 cc Bottle)